




UNDONE

INDIVIDUALITY MATTERS

AQUA - USER MANUAL

Before enjoying your AQUA timepiece, please read this instruction manual carefully for its proper use and care.


- **200 METER WATER RESISTANCE**
 - Suitable for scuba diving
- **SCREW DOWN CROWN**
 - Unlock for time adjustment
- **ROTATING BEZEL**
 - Elapsed time measurement during diving (Up to 60 minutes)
- **TIME/CALENDAR**
 - Hour, minute & second hands
 - Date



HOW TO START THE WATCH


This is an automatic mechanical watch. To initially start your watch, swing it from side to side in a horizontal motion for about 30 seconds.

* If the watch is worn on the wrist, the mainspring will be wound automatically through normal wrist movement.



TIME / CALENDAR SETTING

Date Setting




- 1** Unlock **CROWN**
- 2** Pull out **CROWN** to **FIRST CLICK** position
- 3** Set the date

NOTES

- 1 Do not change the calendar between 9:00 p.m. and 4:00 a.m. Otherwise, it may not change properly.
- * If it is necessary to set the calendar during that time period, first change the time to any time outside this period, set the calendar and then reset the correct time
- 2 It is necessary to adjust the date at the end of February and 30-day months..

Time Setting



- 4** Pull out **CROWN** to **SECOND CLICK** position
- 5** Set the time
Hack mechanism is now activated. (Second hand stopped)
- 6** Push back **CROWN** in to **NORMAL** position
(Second hand resumes)
- 7** Lock **CROWN**
(To activate water resistance for diving)

NOTES

- 1 First set the hands to a time a few minutes earlier than the correct time, and then advance them to the exact time.
- 2 Check that AM/PM is correctly set.
- * Turn the hands past the 12 o'clock marker. If the date changes, the time is set for the A.M. period. If it does not change, the time is set for the P.M. period.